


# SRT278 AVANT Fleet Serial Cable Operation

Document Revision 1.1.3  
July 2011



## **Operating modes**

### **Normal mode**

This is the intended operating mode, where the unit is not connected to anything through its serial connector. Communication with the unit is carried out through SMS or GPRS (UDP).

The unit will run in normal mode if the serial connector is either unplugged or the RTS signal is disabled / left floating.

### **Normal mode with debug output**

For diagnostics, the unit can have the serial connector enabled for debug output, and still remain in normal operating mode. This is accomplished by plugging in the serial connector while leaving the RTS signal disabled / left floating, and setting the signal DBGMODE(Pin B:2) high, for example by connecting it to VBATT(Pin B:1).

A terminal program capable of handling serial communication at 115200bps, 8 data bits, 1 stop bit and no parity with flow control disabled is required to monitor the debug output.

### **External configuration and test mode**

For local configuration and diagnostics, the unit can be started in a configuration mode, where normal events and other functions are disabled. This is accomplished by plugging in the serial connector to a computer while the GSM is *not active*, and having the signal DBGMODE(Pin B:2) left floating.

A terminal program capable of handling serial communication at 115200bps, 8 data bits, 1 stop bit and no parity with flow control enabled is required to use this mode.

The configuration mode will be maintained for as long as the RTS signal is active, normally as long as the serial cable is connected and the terminal program running.

### **Programming mode**

Programming mode is required to safely upgrade the firmware.

In order to enter programming mode, make sure the GSM is off and the serial cable is not connected, then connect the signal DBGMODE (Pin B:2) input to VBATT (Pin B:1), and then connect the serial cable to a computer running a terminal program capable of handling serial communication at 115200bps, 8 data bits, 1 stop bit and no parity with flow control enabled.

## ***Manual firmware upload***

**Caution! Erroneous firmware upgrades may result in a non-operating unit.**

Start the unit in programming mode, and send the command `AT#FWFORMAT` to the unit. The unit should then eventually respond with `OK`.

Proceed with the command `AT#FWUPLOAD` to upload the new firmware. Depending on the terminal program of choice may or may not output a continuous sequence of a single character. Proceed with transfer of the firmware file by X-Modem.

Finally, provided the transfer was successful, install the firmware with the command `AT#FWINSTALL`. The unit should respond with `Installing`, followed by a restart.

**Caution! Only use firmware files supplied by SRT in the “.sff” format when updating the firmware.**

When done, disconnect the serial cable.

## Appendix A – Upgrade example

```
:::
:::MP SRT278 Fleet 9.1.0 Build: Jun 23 2011 08:41:09/SRT
::: R7.44.0.201008311212.Q2687RD 8192.22544.1017840
:::
:::(C) Copyright Scandinavian Radio Technology AB
:::
:::2011-07-26 09:30:01
:::
:::PREPARING PROGRAMMING MODE...
:::STARTING PROGRAMMING MODE...
:::PROGRAMMING MODE READY!
AT#FWFORMAT
Format: 0%
Format: 8%
Format: 16%
Format: 24%
Format: 33%
Format: 41%
Format: 49%
Format: 57%
Format: 66%
Format: 74%
Format: 82%
Format: 90%
Format: 100%
OK
AT#FWUPLOAD
$$$$$
Packets: 1422/72
OK
AT#FWINSTALL
Installing
OK
:::
:::MP SRT278 Fleet 9.1.1 Build: Jul 25 2011 10:09:02/SRT
::: R7.44.0.201008311212.Q2687RD 8192.22564.1017820
:::
:::(C) Copyright Scandinavian Radio Technology AB
:::
:::2011-07-26 09:33:39
:::
:::FIRMWARE UPDATED!
:::PREPARING PROGRAMMING MODE...
:::STARTING PROGRAMMING MODE...
:::PROGRAMMING MODE READY!
```

X-Modem upload of the  
9.1.1 firmware file prior to  
**AT#FWINSTALL.**

## Appendix B – Commands in external mode

**Caution! These commands are for testing purposes only and may vary for different firmware revisions.**

### AT#AIN1 – AIN1 voltage

Command	<i>AT#AIN1</i>
Response	<i>#AIN1: ymV</i> <i>OK</i>

y	AIN1 voltage in mV.
---	---------------------

### AT#AIN2 – AIN2 voltage

Command	<i>AT#AIN2</i>
Response	<i>#AIN2: ymV</i> <i>OK</i>

y	AIN2 voltage in mV.
---	---------------------

### AT#AUX – AUXALARM input

Command	<i>AT#AUX</i>
Response	<i>#AUX: y</i> <i>OK</i>

y	AUXALARM input level, HIGH or LOW.
---	------------------------------------

### AT#AUXCTRL – AUXCTRL input

Command	<i>AT#AUXCTRL</i>
Response	<i>#AUXCTRL: y</i> <i>OK</i>

y	AUXCTRL input level, HIGH or LOW.
---	-----------------------------------

### AT#BAT – Battery voltage

Command	<i>AT#BAT</i>
Response	<i>#BAT: ymV</i> <i>OK</i>

y	Battery charge in mV.
---	-----------------------

### AT#DEF – Write default settings

Command	<i>AT#DEF</i>
Response	<i>OK</i>

### AT#GPSOFF – GPSOFF input

Command	<i>AT#GPSOFF</i>
Response	<i>#GPSOFF: y</i> <i>OK</i>

y	GPSOFF (PRV) input level, HIGH or LOW.
---	--

### AT#IGN – Ignition

Command	<i>AT#IGN</i>
Response	<i>#IGN: y</i> <i>OK</i>

y	Ignition state, HIGH or LOW.
---	------------------------------

### AT#IR – IR input

Command	<i>AT#IR</i>
Response	<i>#IR: y</i> <i>OK</i>

y	IR input level, HIGH or LOW.
---	------------------------------

### AT#MODEMMODE – Modem Mode input

Command	<i>AT#MODEMMODE</i>
Response	<i>#MODEMMODE: y</i> <i>OK</i>

y	Modem Mode input level, HIGH or LOW. <i>Note: Currently not used</i>
---	---

### AT#MP – Main power voltage

Command	<i>AT#MP</i>
Response	<i>#MP: ymV</i> <i>OK</i>

y	Main power voltage in mV.
---	---------------------------

### AT#PB – Push button input

Command	<i>AT#PB</i>
Response	<i>#PB: y</i> <i>OK</i>

y	Digital input level, HIGH or LOW.
---	-----------------------------------

## AT#PBIN – SRT278 Fleet binary protocol

Command	AT#PBIN=" <u>xx...xx</u> "
Response	#PBIN: <u>a,b,n</u> , " <u>yy...yy</u> " (possibly multiple lines) OK

xx...xx	Hex representation of the binary command or configuration to execute.
yy...yy	Hex representation of the binary response to the above command.
a	Response line number. Always starts with 1 for the first response for every command. If the response requires multiple lines, the value is increased by one for each line.
b	Total response lines.
n	Number of hex characters in the current line's data field.

## AT#PIN – Set/clear PIN

Command	AT#PIN=" <u>xxxx</u> "
Response	OK

Command	AT#PIN?
Response	#PIN: "SET" OK
Response	#PIN: "NONE" OK

xxxx	PIN code to use. An empty string will clear the setting.
------	--

## AT#RLI2O – Connect Relay-IN to Relay-OUT

Command	AT#RLI2O= <u>x</u>
Response	OK

x	1 to connect relay in to out, 0 to not connect relay in to out. <i>Note: The relay connection will reset right away</i>
---	--

## AT#TEMP – Temperature reading

Command	AT#TEMP
Response	#TEMP : <u>xy.yyyy</u> OK
Response	#TEMP: <u>NONE</u> OK

x	+ or -
y.yyyy	Temperature in degrees Celcius.
NONE	Temperature sensor not detected.

## AT#VER – Version information

Command	AT#VER
Response	#VER: "SRT278 Fleet <u>x.x.x</u> Build: <u>d...d</u> /SRT", "HW: <u>z</u> ", "PIC: <u>y</u> " OK

x.x.x	GSM firmware version. Three numbers, major version, minor version and revision.
y	PIC firmware version, one number.
z	Hardware revision, one number.
d...d	Build date for GSM firmware, month dd yyyy hh:mm:ss

## AT#VIB – Vibration sensor status

Command	AT#VIB
Response	#VIB: <u>y</u> OK

y	Vibration sensor state, HIGH or LOW.
---	--------------------------------------



## Appendix C – Hardware connectors

This section is intended as a quick reference for the connectors' locations and the numbering for Control A, Control B and Control C pins. Please refer to the document "SRT278 Avant Fleet User's Manual" for details about the connectors.

