


Quickstart guide SRT299

Turn on/off



Use the on/off-switch on the bottom of the device.

The device vibrates shortly after a few seconds and turns itself on or off.




Sending an alarm



Press the alarm button until the device vibrates.

The device vibrates as soon as the alarm is registered.



Charging the batteries






Connect the USB-cable to the device.

The charge indicator LED blinks red or green during charging.



When the device is fully loaded the charge indicator LED turns to a solid red or green.



Status LEDs

GSM status



Solid

Searching for a GSM network.

Slow blinking

Connected to a GSM network.

Rapid blinking

Voice call in progress.

Turned off

The device is either turned off or in sleep mode.

GPS-status



Blinking

The device has a recent GPS position.

Turned off

The GPS is either turned off, in sleep mode or missing a recent GPS position.

Charge indicator LED (no charger connected)



Blinking three times every 15 seconds

The device is on and shows the battery status with three blinks.

Battery level very good

● green ● green ● green

Battery level good

● green ● green ● red

Battery level low

● green ● red ● red

Battery level critical

● red ● red ● red

Alternating between solid red and green.

The device is shutting down.

Charge indicator LED (charger connected)



Blinking green every other second

The device is on and charging.

Blinking red every other second

The device is off and charging.

Solid green

The device is on and fully charged.

Solid red

The device is off and fully charged.

Alternating between solid red and green.

The device is shutting

