### Turn on/off

Move switch into on or off position

The personal alarm vibrates shortly and thereafter turns on/off.



# Sending an alarm


Press the alarm button until the device vibrates.

The personal alarm vibrates as soon as the alarm is registered.



# **Quickstart guide SRT326**

SRT3260210A14\_QG\_EN\_STD





### **Status LEDs**

### **GSM** status LED

Solid
Searching for a GSM
network

Slow blinking Connected to a GSM

Rapid blinking Voice call in progress

Turned off
The device is

The device is either turned off or in sleep

### **Timer status LED**

**Turned off** Timer alarm not active.

Blinking (red)
Timer alarm active.

Charge indicator LED (no charger connected)

Blinking three times every 15 seconds

The device is on and shows the battery status with three flashes:

Very good

green green green

Good

green green red

Low

green red red

Critical

red

red

red

Alternating between solid red and green

The device is shutting down

Charge indicator LED (charger connected)

Blinking green every other second

The device is on and charging

# Blinking red every other second

The device is off and charging

### Solid green

The device is on and fully charged

#### Solid red

The device is off and fully charged

Alternating between solid red and green

The device is shutting down

# Charging (desktop stand)

Place the unit in the charge stand.

## **Charging (USB)**

Lift the rubber flap on the side of the device.

Insert the charger cable into the mini USB connector.

The charge indicator LED will blink red or green when charging.

The charge indicator LED will turn into a solid red or green when the device is fully charged.

### **Charging times**

Before using your alarm device the first time it should be charged for 4 hours. Whenever the battery is fully discharged it should be charged for at least 4 hours. The device should be charged daily.

