


Quickstart guide SRT334i

SRT3340100A06_QG_EN_STD

Turn on/off

Before attempting to turn the device on, make sure it is connected to a power outlet. Then press and hold the On/Off button for at least 5 seconds until all three status LEDs start flashing.

To turn off the device press and hold the On/Off button until all status LEDs turn off.



Status LEDs

Power status LED

Solid

Power is connected.

Blinking

The device is not receiving power.

No light

The device is turned off.



Battery status LED

Solid


The battery is charged.

Blinking

The battery level is low.

No light

The device is turned off.



Status LEDs

Tag vicinity indicator LED

Solid

The device is not within the transmission range of another tag.

Blinking

The device is within the transmission range of another tag.

No light

The device is turned off.

