




## Quickguide

SRT405 / SRT405i



## Installing SIM-card

Open the small hatch on the side and slide the SIM-card into the holder. The cut corner should be placed inward left. See picture.




## Charging

A new device must be charged before first use. Approximately 4 hours to fully charge the battery.

Charging in progress indicates on the display.

## Installing belt clip

The included belt clip mounts by angling the unit between the arms of the belt clip while they are gently forced apart. See the image below.



## Alarm button and function buttons

To send an Alarm, press the Alarm button and hold until the device vibrates.

Function buttons F1 and F2 can be configured to manage a set of different functions such as Man down, timer alarm or establishing a voice call to a predefined set of numbers. If you are unsure how the device is configured please contact your retailer.

## Display

To light the display simply press the PWR button once. The display then shows actual status.

Battery level	98%
Positionstatus	GPS: Yes
Networkstatus	GSM: 4G
	Date: 22-05-20

## Turning on and off the device

To turn on or off the device simply press and hold the PWR button for at least 5 seconds.

## Acoustic warning

The device will make an acoustic warning if the SIM-card is missing or not inserted correctly.